# HME 150W Series

# hivolt.de

### 1kV - 30kV; 150W VERSATILE, PRECISION REGULATED HIGH VOLTAGE POWER SUPPLIES

### FEATURES

- Precise high voltages up to 30kV at max. 150W
- Positve or negative polarity
- Output voltage and current control
- Internal reference voltage
- Stable output voltage
- Low ripple and noise
- Low EMI
- Capacitor charger and arc management options
- Patented resonance converter technology
- Metal case
- Modified versions available on request
- Made in Germany



HME modules are versatile, precise and stable analog controlled high voltage power supplies with multiple options. The HME series covers output voltages of up to 30kV in a compact metal box. The maximum output power is 150W. The HV output is brought out via an HV cable. The control voltages and analog I/O are connected via a D-Sub 9 connector. The control of output voltage and current is achieved by means of control voltages or potentiometers (internal reference voltage). Remote ON and INHIBIT inputs, as well as output voltage and output current monitoring outputs, are provided.

The HME modules can be equipped as capacitor charger with very low output voltage overshoot (option C). They also can be protected against high-frequency arcs (option A).

For medium quantities the devices can be equipped with a Safety-Interlock loop.

The patented resonant converter technology and the metal box shielding guarantee high efficiency and low EMI.

The HME modules can be used as standalone DC/DC converters or combined into THQ series multichannel AC/DC HV power supplies.

Output Voltage V <sub>NOM</sub>	Max. Output Current Імом	Μ	Ripple / Noise	
		Positive Polarity Output	Negative Polarity Output	typ.
0 – 1 000V	150mA	HME-1P150-24-#	HME-1N150-24-#	0.5Vpp
0 – 2 000V	75mA	HME-2P75-24-#	HME-2N75-24-#	1Vpp
0 – 4 000V	40mA	HME-4P40-24-#	HME-4N40-24-#	2Vpp
0 – 8 000V	20mA	HME-8P20-24-#	HME-8N20-24-#	4Vpp
0 – 12 000V	12.5mA	HME-12P12.5-24-#	HME-12N12.5-24-#	6Vpp
0 – 15 000V	10mA	HME-15P10-24-#	HME-15N10-24-#	7.5Vpp
0 – 20 000V	7.5mA	HME-20P7.5-24-#	HME-20N7.5-24-#	10VPP
0 – 30 000V	5mA	HME-30P5-24-#	HME-30N5-24-#	15V <sub>PP</sub>

#: set/monitor voltage range designator: "5" or "10" for 0-5V or 0-10V respectively

#### OPTIONS

- **A** protection against high-frequency arcs
- **C** capacitor charger with very low output voltage overshoot

 $\ensuremath{\mathbb{C}}$  2016 hivolt.de - Subject to change without notice, errors expected.

HME\_150W AA 02/2016 Page 1 of 3

# HME 150W Series

SPECIFICATIONS				
Input Supply Voltage (VIN):	+21Vpc to +29Vpc	(max 9A)		
Line Regulation:	< 1 * 10 <sup>-4</sup> * V <sub>NOM</sub> (	$\Delta V$ out / $\Delta V$ in	min to max sup	ply voltage)
Load Regulation:	< 2 * 10 <sup>-4</sup> * V <sub>NOM</sub> (	$\Delta V$ out / $\Delta R$ load	no load to rated	load)
Temperature Coefficient:	2 * 10 <sup>-4</sup> /K			
Supply Connector:	2-pole screw terminal block, max. 2.5mm <sup>2</sup>			
Control Connector:	D-Sub 9 male			
Output:	shielded HV cable (600mm)			
Control:	analog control signals: VSET, ISET, VMON, IMON 5V control inputs: INH, ON			
Reference Voltage (V <sub>REF</sub> ):	5V or 10V (model dependent). This reference voltage is intended for external potentiometers to program the output voltage and/or current (connect wiper to VSET, ISET)			
Voltage Setting (VSET):	oltage Setting (VSET): Vvset=0 to Vref results in Vour		to V <sub>NOM</sub> ±1%	(input impedance: 10MΩ)
Current Limit Setting (ISET):	VISET = 0 to VREF results in IOUT =		о Inom ±1%	(input impedance: 10MΩ)
Voltage Monitor (VMON)	VOUT = 0 to VNOM results in VVMON = 0 to VREF			
Current Monitor (IMON)	lout = 0 to Inom results in Vimon = 0 to Vref			
Remote ON (ON)	active Low Low (0V to 1V): High (3.5V to 10V) o	( V ropen: V	10kΩ pullup to +5V Yout according to V Yout = 0 with ramp of	′) изет with ramp ca. Vnoм/4s ca. Vnom/4s
Inhibit (INH)	active Low Low (0V to 1V): High (3.5V to 10V) o	( V ropen: V	10kΩ pullup to +5V Ίουτ off Ίουτ according to V\	r) VSET
Protection:	Supply overvoltage overvoltage, over-te <b>Only one short circ</b> In case of higher ar	and undervolt emperature. <b>uit or arc eve</b> r c/S.C. frequer	age, overload, arc <b>nt per second allo</b> icy the RMS outpu	, output short circuit, output <b>wed!</b> t current must be limited to INOM
Operating temperature:	0°C to +65°C			
Cooling:	Built-in fan (max 2	20m³/h)		
Storage temperature:	-25°C to +80°C			
Dimensions (LxWxH):	188 x 185 x 59.5 mm	n <sup>3</sup>		
Weight:	1.5kg to 1.75kg, dep	pending on mo	del	

All voltages are referenced to GND

### - CONNECTION DIAGRAM



## PIN FUNCTION DESCRIPTIONS

Pin No.	Designation	Function
1	GND (OV)	Signal GND (conn. to pin 6)
2	IMON	Current Monitor Output
3	INH	Inhibit Input
4	ISET	Current Progr. Input
5	ON	Remote On Input
6	GND	Signal GND (conn. to pin 1)
7	VMON	Voltage Monitor Output
8	VSET	Voltage Progr. Input
9	REF	Reference Voltage Output
	+VIN	Input Supply Voltage
	-VIN	Supply Voltage Ground

GND, -VIN and HVRTN are internally connected; the case is connected to GND.

© 2016 hivolt.de - Subject to change without notice, errors expected.

## **HME 150W Series**

# hivolt.de

#### DIMENSIONS



Dimensions in mm, drawing not to scale

#### ORDERING INFORMATION



HME-2P75-24-5-C (HME series, 2kV, positive polarity, 30mA, 24V supply, 5V reference, capacitor charger option)

#### Disclaimer

The information given in this data sheet is technical data, not assured product characteristics. It has been carefully checked and is believed to be accurate; however, no responsibility is assumed for inaccuracies. The user has to ensure by adequate tests that the product is suitable for his application regarding safety and technical aspects. hivolt.de GmbH & Co. KG does not assume any liability arising out of the application or use of any product described.

#### Safety Advice

Design, installation and inspection of machinery and devices carrying high voltage require accordingly trained and qualified personnel. Appropriate safety rules and directives must be complied with.

Improper handling of high voltage can mean severe injuries or death and may cause serious collateral damage!

HME\_150W AA 02/2016 Page 3 of 3